



NXT2

 Arrange boxed light fixtures on floor in specified mounting locations; remove fixtures from boxes.



- Turn bracket knobs on fixture counter-clockwise to loosen.
- Slide wire bracket beneath the knobs.
- Rotate knobs clockwise to tighten, securing bracket in place.




• Slide reflector into collar at an angle, so that outer rim is inserted beneath the collar tabs.

(Note: Wear cotton gloves or wash hands thoroughly with soap & water to remove any grime/oils before handling reflector.)




· Using both hands, adjust the reflector from the inside, by gently pressing outwards until the outer rim fits securely beneath the collar tabs on all sides.

(Note: Wear cotton gloves or wash hands thoroughly with soap & water to remove any grime/oils before handling reflector.)



- · Always check the fixture label prior to installing a Metal Halide (MH) lamp to ensure your fixture is compatible.
- Always ensure that the lamp is "open-rated" when installing a MH lamp.




- · Slide the plastic locks outwards.
- Install lamp, ensuring side with "getter" is closest to electronics compartment. If lamp is HPS, ensure burner filament is on top (away from reflector).

(Note: Always wear cotton gloves when handling double-ended lamps.)

ATTENTION: Install in accordance with national and local building and electrical codes.






NXT2

- Slide locks back in place to secure lamp.
- Ensure that the sliding mechanism has fully closed against the stop, as loose connections may cause arcing—potentially creating a fire risk and/or voiding warranties.




Note: This step is for Wieland Connector power cord option ONLY.

• Install Wieland connector box / receptacle (sold separately) in suitable locations.



· Raise fixture to ceiling and slide mounting bracket over the track/truss; ensuring fixture is securely in place.



• Use integrated level on back of the housing to adjust the light fixture. Fixture is level when spirit level bubble is centered.



• Connect power cord from fixture to power supply.